


BREAKDOWN TR-308



N°	REFERENCE	DESCRIPTION
1	05TR0000224	Mandrel M-8
2	05TR0000225	Nosepiece M-8
3	05TR0000203	Locknut
4	05TR0000201	Nosepiece case
8	05BM0000204	Main body
9	05BM0000205	Screws + nut
10	05BM0000206	Handle (1 unit)
11	05TR0000208	Expansion piece
12	05BM0000209	Plates (4 units)
13	05BM0000207	Piston
14	05TR0000214	Adjustment nut
15	05BM0000210	Anchoring pistons
16	05BM0000211	Mandrel collector
17	05TR0000212	Knob
18	05TR0105006	Mandrel M-3

N°	REFERENCE	DESCRIPTION
19	05TR0000217	Nosepiece M-3
20	05TR0105008	Mandrel M-4
21	05TR0000219	Nosepiece M-4
22	05TR0105010	Mandrel M-5
23	05TR0000221	Nosepiece M-5
24	05TR0105012	Mandrel M-6
25	05TR0000223	Nosepiece M-6
29	05BM0000100	Nosepiece Spanner
30	05BM0000109	Wrench 12-18

OPTIONAL FOR GROOVED STUD NUT

26	05TR0000234	Mandrel (female) M-5
27	05TR0000235	Mandrel (female) M-6
28	05TR0000236	Mandrel (female) M-8