




PARTS LIST

No.	Description	No.	Description	No.	Description
1	Bolt M5×20	18	Rectangle Washer	35	Pipe
2	Exhaust Cap	19	Trigger Valve Stem	36	Compressed Spring
3	Compressed Spring	20	Trigger Valve Pipe	37	Washer 4
4	Rectangle Washer	21	O-ring 1.7×2	38	Bolt M4×4
5	Cylinder Cover	22	Trigger Valve Guide	39	Bolt M4×8
6	O-ring 2.1×11.7	23	O-ring 11.2×2	40	Fixed Seat
7	O-ring 2.1×16.2	24	Safety	41	Nut M4
8	Head Valve Piston	25	Compressed Spring	42	Fix Pin
9	Collar	26	Step Pin	43	Spring
10	O-ring 2.65×30.2	27	Trigger	44	Release Latch
11	Cylinder	28	E-ring ø 2.5	45	Release Handle
12	O-ring 2.65×18	29	Spring Washer 5	46	Nut M5
13	Main Piston	30	Driver Guide	47	Rubber Handle Case
14	Bumper	31	Spacer	48	O-ring 35.5×2.3
15	Sealing Washer	32	Fixed Magazine	49	End Cap
16	Gun Body	33	Movable Magazine	50	Air Inlet Plug
17	Rubber Washer	34	Pusher		

Note: if you need spare parts of this model, pls feel free to contact us or the distributor where you bought this tool. Tks!